
















## Screws

	1"	1-1/8"	1-1/4"	1-1/2"	1-5/8"	2"	2-1/4"	2-1/2"	3"	3-1/4"	3-1/2"	4"	5"	6"
<b>Drywall Screws Coarse</b>				X						X	X	X	X	X
				X						X	X	X	X	X
<b>Drywall Screws Fine</b>		X		X						X	X	X	X	X
		X		X						X	X	X	X	X
<b>Wafer Head Self Drill</b>	1/2"	X		X			X	X	X	X	X	X	X	X
		X		X			X	X	X	X	X	X	X	X
<b>Flooring Screws</b>		X					X			X	X	X	X	X
		X					X			X	X	X	X	X
<b>Yellow Zinc Screws</b>	1"	X					X			X				
		X					X			X				
<b>Trim Head Screws</b>	X	X	X	X		X		X		X	X	X	X	X
	X	X	X	X		X		X		X	X	X	X	X
<b>Stainless Trim Head Screws</b>	X	X	X	X	X	X				X	X	X	X	X
	X	X	X	X	X	X	X			X	X	X	X	X
<b>Ext. Deck Screws ACQ</b>	X	X					X			X				
	X	X					X			X				
<b>Laminating Screws</b>	X	X	X		X	X	X	X	X	X	X	X	X	X
	X	X	X		X	X	X	X	X	X	X	X	X	X
<b>Wafer Head Screws</b>	X			X	X		X	X	X	X	X	X	X	X
	X			X	X		X	X	X	X	X	X	X	X
<b>Ext. Trim Head Screws ACQ</b>	X	X		X	X	X				X	X	X	X	X
	X	X		X	X	X				X	X	X	X	X
<b>Stainless 305 Deck Screws</b>	X	X	X		X					X		X	X	X
	X	X	X	X	X					X		X	X	X
<b>Bugle Head Self Drill</b>	X			X			X			X	X	X	X	X
	X			X			X			X		X	X	X